

TG-240/360

ARGB





User's Manual





Dongguan Sibositong Industrial Co., Ltd.

No.5, Xinglong Lu, Sanzhong Village, Qingxi Town, Dongguan City,
Guangdong Province, 523651, China

© 2022 JONSBO Technology Co., Ltd. All right reserved. Specifications are subject to change without prior notice. Some trademark may be claimed as the property of others.



Chapter 1 - Part List

A CPU Cooler CPU Kühler Ventirad CPU 쿨러 (방열기) Disipador de calor CPU CPU散热器	
B Intel Backplate Intel Backplate Intel Contre Plaque 백플레이트 Placa trasera Intel 背板	
C Intel Bracket Intel Halterung Intel Bracket 인텔 브래킷 Soporte Intel Intel 支架	
D AMD Bracket AMD Halterung AMD Bracket AMD 브래킷 Soporte AMD AMD 支架	
E INTEL 115X/1200 Screw INTEL 115X/1200 Schraube Vis INTEL 115X/1200 인텔 115X/1200 나사 Tornillo INTEL 115X/1200 Intel 115X/1200间隔柱 X4	

F INTEL 1700 Screw INTEL 1700 Schraube Vis INTEL 1700 인텔 1700 나사 Tornillo INTEL 1700 Intel 1700间隔柱 X4	
G AMD Screw stud AMD-Schraubbolzen Goujon à vis AMD AMD 나사 스테드 Tornillo AMD AMD螺杆 x4	
H nut Nuss noix 너트 tuerca 螺母 X4	
I Thermal Paste Wärmeleitpaste Pâte thermique 써멀 페이스트 Pasta térmica 散热膏	
J Case Screws Gehäuseschrauben Vis du boîtier 케이스 나사 Tornillos de la caja 机箱螺丝 240: x8 360: x12	

Chapter 2 - Installation

Step1



Installing the Intel / AMD bracket

Installieren der Intel / AMD-Halterung



Installation du bracket Intel / AMD

Intel 설치 / AMD 지지대

Instale el soporte INTEL/AMD

安装Intel / AMD 支架

Step2



Remove the protection film / Applying thermal paste

Entfernen Sie die Schutzfolie / Aufbringen der wärmeleitpaste


Retirez le film protecteur / Application de la pâte thermique

보호막을 뜯어 주세요 / 방열 써멀구리스를 바르고


Quitar película protectora / Aplicar grasa térmica

取下保护膜 / 涂抹散热膏


Step3




Step3.1




Step4



Step4.1



Step5



Connect the 3-pin connector from the pump unit to AIO/PUMP socket on the motherboard

Verbinden Sie den 3-poligen Stecker der Pumpeneinheit mit der AIO / PUMP-Buchse auf der Hauptplatine

Connectez le connecteur à 3 broches de la pompe à la prise AIO / PUMP de la carte mère

3PIN 커넥터를 메인보드 AIO/PUMP 콘센트에 연결해 주세요

La interfaz de fuente de alimentación de 3 pines en la cabeza fría está conectada al pin AIO/PUMP de la placa base

冷头上3PIN供电接口连接至主板AIO/PUMP插针

Connect the 4-pin fan PWM connector to CPU_FAN socket on the motherboard

Verbinden Sie den 4-poligen Lüfter-PWM-Anschluss mit der CPU_FAN-Buchse auf dem Motherboard

Connectez le connecteur PWM du ventilateur à 4 broches à la prise CPU_FAN de la carte mère

4핀 팬 PWM 커넥터를 마더보드의 CPU_FAN 소켓에 연결합니다

El cable de alimentación PWM de 4 pines del ventilador está conectado al pin CPU-FAN de la placa base

风扇4PIN PWM供电线连接至主板CPU-FAN插针

Connect to 5V ARGB LED socket on motherboard

An die 5V-ARGB-LED-Buchse auf dem Motherboard anschließen


Connectez-vous à la prise LED ARGB 5V sur la carte mère

마더보드의 5V ARGB LED 소켓에 연결

Conéctese al pin ARGB de 5V correspondiente en la placa base

连接至主板对应5V ARGB插针

Step6



Secure the the fans and radiator

Lüfter und Kühler sichern

Ventilateur et refroidisseur sécurisés

고정 팬(FAN) 및 라디에이터(Radiator)

Fijación del radiador al chasis

固定冷排至机箱

Secure the cooler -Intel LGA 115X/1200

Den Kühler sichern -Intel LGA 115X/1200

Fixez la glacière -Intel LGA 115X/1200

고정 쿨러 (방열기) - Intel LGA 115X/1200

Disipador de calor fijo - Intel LGA 115X/1200

固定散热器 -Intel LGA 115X/1200

Secure the cooler -Intel LGA 1700

Den Kühler sichern -Intel LGA 1700

Fixez la glacière -Intel LGA 1700

고정 쿨러 (방열기) - Intel LGA1700

Disipador de calor fijo - Intel LGA 1700

固定散热器 -Intel LGA1700

Secure the cooler -AMD

Den Kühler sichern -AMD

Fixez la glacière -AMD

고정 쿨러 (방열기) - AMD

Disipador de calor fijo - AMD

固定散热器 -AMD