

TG-420 ARGB

User's Manual


Dongguan Sibositong Industrial Co., Ltd.

No.5, Xinglong Lu, Sanzhong Village, Qingxi Town, Dongguan City,
Guangdong Province, 523651, China


© 2023 Dongguan Sibositong Industrial Co., Ltd. All right reserved. Specifications are subject to
change without prior notice. Some trademark may be claimed as the property of others.

Chapter 1 - Part List

A CPU Cooler
CPU Kühler
Ventirad
CPU 쿨러 (방열기)
Disipador de calor CPU
CPU散热器



B Intel Backplate
Intel Backplate
Intel Contre Plaque
백플레이트
Placa trasera
Intel 背板




D AMD Bracket
AMD Halterung
AMD Bracket
AMD 브래킷
Soporte AMD
AMD 支架



C Intel Bracket
Intel Halterung
Intel Bracket
인텔 브래킷
Soporte Intel
Intel 支架




E Intel 115X/1200 Spacer
Intel 115X/1200 Abstandshalter
Entretoise Intel 115X/1200
인텔 115X/1200 스페이서
Espaciador Intel 115X/1200
Intel 115X/1200 间隔柱
X4



F Intel 1700 Spacer
Intel 1700 Abstandshalter
Entretoise Intel 1700
인텔 1700 스페이서
Espaciador Intel 1700
Intel 1700 间隔柱
X4




H nut
Nuss
noix
너트
tuerca
螺母 X4




J Case Screws
Gehäuseschrauben
Vis du boîtier
케이스 나사
Tornillos de la caja
机箱螺丝
360/420: x12



G AMD Screw stud
AMD-Schraubbolzen
Goujon à vis AMD
AMD 나사 스톨드
Tornillo AMD
AMD 螺杆
x4





I Thermal Paste
Wärmeleitpaste
Pâte thermique
써멀 페이스트
Pasta térmica
散热膏





Chapter 2 - Installation

Step1




Installing the Intel / AMD bracket
Installieren der Intel / AMD-Halterung
Installation du bracket Intel / AMD
인텔 설치 / AMD 지지대
Instale el soporte INTEL/AMD
安装Intel / AMD 支架

Step2




Remove the protection film / Applying thermal paste
Entfernen Sie die Schutzfolie / Aufbringen der wärmeleitpaste
Retirez le film protecteur / Application de la pâte thermique
보호막을 뜯어 주세요 / 방열 써멀구리스를 바르고
Quitar película protectora / Aplicar grasa térmica
取下保护膜 / 涂抹散热膏


Step3




Step3.1




Step4



Step4.1




Step5



Connect the 3-pin connector from the pump unit to AIO/PUMP socket on the motherboard
Verbinden Sie den 3-poligen Stecker der Pumpeneinheit mit der AIO / PUMP-Buchse auf der Hauptplatine
Connectez le connecteur à 3 broches de la pompe à la prise AIO / PUMP de la carte mère
3PIN 커넥터를 메인보드 AIO/PUMP 콘센트에 연결해 주세요
La interfaz de fuente de alimentación de 3 pines en la cabeza fría está conectada al pin AIO/PUMP de la placa base
冷头上3PIN供电接口连接至主板AIO/PUMP插针
Connect the 4-pin fan PWM connector to CPU_FAN socket on the motherboard
Verbinden Sie den 4-poligen Lüfter-PWM-Anschluss mit der CPU_FAN-Buchse auf dem Motherboard
Connectez le connecteur PWM du ventilateur à 4 broches à la prise CPU_FAN de la carte mère
4핀 팬 PWM 커넥터를 마더보드의 CPU_FAN 소켓에 연결합니다
El cable de alimentación PWM de 4 pines del ventilador está conectado al pin CPU-FAN de la placa base
风扇4PIN PWM供电线连接至主板CPU-FAN插针

Connect to 5V ARGB LED socket on motherboard
An die 5V-ARGB-LED-Buchse auf dem Motherboard anschließen
Connectez-vous à la prise LED ARGB 5V sur la carte mère
마더보드의 5V ARGB LED 소켓에 연결
Conéctese al pin ARGB de 5V correspondiente en la placa base
连接至主板对应5V ARGB插针

Step6



Secure the the fans and radiator
Lüfter und Kühler sichern
Ventilateur et refroidisseur sécurisés
고정 팬(FAN) 및 라디에이터(Radiator)
Fijación del radiador al chasis
固定冷排至机箱

Secure the cooler -Intel LGA 115X/1200
Den Kühler sichern -Intel LGA 115X/1200
Fixez la glacière -Intel LGA 115X/1200
고정 쿨러 (방열기) - Intel LGA 115X/1200
Disipador de calor fijo - Intel LGA 115X/1200
固定散热器 -Intel LGA 115X/1200

Secure the cooler -Intel LGA 1700
Den Kühler sichern -Intel LGA 1700
Fixez la glacière -Intel LGA 1700
고정 쿨러 (방열기) - Intel LGA1700
Disipador de calor fijo - Intel LGA 1700
固定散热器 -Intel LGA1700

Secure the cooler -AMD
Den Kühler sichern -AMD
Fixez la glacière -AMD
고정 쿨러 (방열기) - AMD
Disipador de calor fijo - AMD
固定散热器 -AMD