


Specification / 机箱参数


Type/类型	ATX case	
Dimensions/尺寸	216.4W x 475.5D x 497H(mm)	
Drive/驱动	3.5"	3
	2.5"	3
Mainboard/主板	E-ATX/XL-ATX/ATX/M-ATX/ITX	
Power/电源	PSII	
Front I/O/面板	USB3.0 x2, USB2.0 x2, Audio x 1, Mic x 1	
Fans/风扇	Front/前	3 x 120mm/140mm(Optional)
	Back/后	1 x 120mm/140mm(120 Fan is built in)
Slots/扩展槽	7	
Weight/重量	N. W./净重: 11.1KG, G. W./毛重: 13.5KG	

Attention: Due to the different versions, if there are any differences between the contents of this manual and the product, please regard the actual product as the truth.

注：因产品的版本不同，如产品实物与本说明书内容描述不符，请以实物为准。




Installation Procedure / 推荐安装步骤




Unscrew 4 screws from rear plate, and then remove the panel.
松开钢板四颗螺丝，取下钢板。


2



Install PSU, lock with the screws.
装上电源，锁上螺丝。




Install motherboard, lock with the screws.
装上主板，锁上螺丝。




Take out PCI block plate and then install display card, lock with toolless screws.
取出PCI挡片，装上显卡，用螺丝固定。

3


1



05 Install 3.5" hard disk and SSD.
装上3.5寸硬盘和SSD硬盘。



06 Installing supported cooling system.
支持的散热系统安装情况。



07 Install side plates, lock with toolless screws.
装上侧板，锁上无工具的螺丝。

Attention / 注意事项

- * Please refer to the procedure of this menu and install step by step.
- * Please pay attention to the direction and order for installing hard disk, CD-Rom, CD-Rom bracket and hard disk bracket.
- * If your motherboard only provides AC97 port, please pay attention not to plug HD Audio connector into it, otherwise it may damage your motherboard.
- * 为了方便安装，请参考本说明书的推荐流程，按先后顺序进行安装。
- * 安装硬盘、光驱、光驱架、硬盘架时请注意安装方向和安装顺序。
- * 如果主板的音频接口是AC97接口，请勿插入HD AUDIO接头，否则会损毁主板。

Accessory Box / 配件包说明

	Stand off for MB 主板垫圈	5 PCS		Screw for MB 主板螺丝	12 PCS
	Screw for 2.5 SSD 2.5硬盘螺丝	16 PCS		Screw for PSU 电源螺丝	5 PCS
	Screw for 3.5 HDD 3.5硬盘螺丝	4 PCS		Cable Tie 束线带	10 PCS

Connection Guide / 连接说明

<p>USB 2.0 Connection / 连接</p> <p>USB+V LP- LP+ GND NC</p> <p>USB+V LP- LP+ GND</p>	<p>USB 3.0 Connection / 连接</p> <p>BB+ BB- BB2+ BB2- BB1+ BB1- GND NC</p>
<p>HD AUDIO Connection / 连接</p> <p>AUX_GND PRESENCE SENSE1_RETURN SENSE2_RETURN POINT 1L POINT 1R POINT 2L POINT 2R</p>	
<p>Power Switch 电源开关连接</p> <p>PWR+ PWR-</p>	<p>Power LED 电源灯连接</p> <p>PWR+ PWR-</p>
<p>Reset Switch 复位开关连接</p> <p>RST+ RST-</p>	<p>H.D.D. LED 硬盘灯连接</p> <p>LED+ LED-</p>